

Floor sensor should be fitted into a piece of flexible conduit & inserted in the floor approx 25mm below the finished level if using a timber floor finish or inserted into a routed groove at finished level if it using a tiled floor finish







UNDERFLOOR HEATING

SYSTEMS LTD

69 CASTLEHAM ROAD
St.LEONARDS-ON-SEA,EAST SUSSEX
TN38 9NU
TEL: 0800 454569
http://www.underfloorheating.co.uk

UNDERFLOOR HEATING SYSTEM PIPEWORK LAYOUT